

2022 BA13TD SERIES THUMBHOLE



BA 123-222	BA 123-243	BA 121-300B	BA 122-300B	BA 121-308	BA 121-308S	BA 123-308	BA 122-308S	BA 123-3006	BA 123-4570	BA 123-8X5	BA 123-223ST	BA 123-665T	BA 123-3085T	BA 123-223G	BA 123-66G
------------	------------	-------------	-------------	------------	-------------	------------	-------------	-------------	-------------	------------	--------------	-------------	--------------	-------------	------------

Item	Description	BA 123-222	BA 123-243	BA 121-300B	BA 122-300B	BA 121-308	BA 121-308S	BA 123-308	BA 122-308S	BA 123-3006	BA 123-4570	BA 123-8X5	BA 123-223ST	BA 123-665T	BA 123-3085T	BA 123-223G	BA 123-66G
1	CAÑON / BARREL						X										X
2	EXTRACTOR / EXTRACTOR	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
3	CUBRE ROSCAS / THREAD PROTECTOR	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
4	BASCULA / FRAME	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
5	MARTILLO / STRIKING PIECE	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
6	MUELLE MARTILLO / STRIKING PIECE SPRING	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
7	LEVA DE CIERRE / LOCKING LEVER	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
8	MUELLE DE TORSION / TORSION SPRING	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
9	PASADOR D=5 / D=5 PIN	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
10	PASADOR LEVA DE CIERRE / LOCKING LEVER PIN	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
11	PERCUTOR / FIRING PIN	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
12	MUELLE DE PERCUTOR / FIRING PIN SPRING	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
13	TORNILLO RETENCION DE PERCUTOR / FIRING PIN RETAIN SCREW	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
14	SPUR / HAMMER SPUR	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
15	PASADOR TOPE APERTURA / OPENING STOP PIN	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
16	MUELLE RETORNO MARTILLO / HAMMER RETURN SPRING	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
17	GUARDAMONTES / TRIGGER GUARD	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
18	MUELLE GATILLO / TRIGGER SPRING	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
19	GATILLO / TRIGGER	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
20	LEVA APERTURA / OPENING LEVER	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
21	MUELLE LEVA APERTURA / OPENING LEVER SPRING	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
22	REMACHE LEVA APERTURA / OPENING LEVEL FIXING PIN	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
23	ESPACIADOR / BUSHING	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
24	PASADOR D=10 / D=10 PIN	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
25	TOPE REGULADOR / ADJUST SCREW	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
26	TUERCA DE BLOQUEO / BLOCKING NUT	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
27	VARILAL REGULACION / ADJUST ROD	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
28	ESPARRAGO DE BLOQUEO / BLOCKING ROD	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
29	CULATA / STOCK	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
30	ARANDELA UNION CULATA BASCULA / FRAME-STOCK WASHER	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
31	TORNILLO UNION CULATA-BASCULA / FRAME STOCK BOLT	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
32	ESCUDDO / GRIP	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
33	TORNILLO AMARRE ESQUADO / GRIP CUP SCREW	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
34	CATONERA / RECOIL PAD	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
35	TORNILLO AMARRE CANTONERA / RECOIL PAD SCREW	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
36	GUARDAMANOS / FOREHAND	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
37	TAPON ROSCADO / SCREW CAP	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
38	TORNILLO CARRIL / TRACK SCREW	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
39	PASADOR EXTRACTOR / EXTRACTOR PIN	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
40	MUELLE EXTRACTOR / EXTRACTOR SPRING	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
41	CARRIL / TRACK	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
42	ESTRUCTURA INTERIOR / INTERNAL STRUCTURE	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
43	TORNILLO AMARRE / LOCKING SCREW	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
44	PASADOR DE PALANCA / HAND LEVER SPRING	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
45	PALANCA / HAND LEVER	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
46	MUELLE DE PALANCA / HAND LEVER SPRING	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
47	PASADOR ELASTICO Ø2x16 / Ø2x16 ELASTIC PIN	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
48	PASADOR ELASTICO Ø2x8 / Ø2x8 ELASTIC PIN	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
49	PORTA CORREAS / SWIVEL SCREW	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X

